


CAPTIVATE INSECT TRAP

Model No. KC097-001

KEY FEATURES



HOW TO USE

1. Connect insect trap to USB outlet
2. Turn the ON/OFF switch to ON. The UV-A LED lights and DC fan will turn on. The UV-A LED lights will begin to attract flying insects, and the DC fan will suck the insects into the trap where they will die of dehydration.
3. When the Insect Trap does not have power ensure the ON/OFF switch is in the OFF position to close the trap door and prevent flying insects from escaping from the cage.

For best results hang the Insect Trap approximately 1.5-2m above the ground or place on a table. The area should be dark with no other light sources and all doors and windows should be closed if using indoors.

HOW TO CLEAN

1. Turn the Insect Trap to OFF and unplug the power source.
2. Open the collection cage by turning the cage anti-clockwise and clean-out.
3. Twist the collection cage clockwise back onto the appliance.

Note: There is a safety micro switch inside the appliance that turns the Insect Trap off when the collection cage is not attached. Please ensure the collection cage is well fixed on the unit, otherwise, the appliance will not work.

WARNING

This unit is strictly to be used under cover.

Keep it away from the children.

Do not insert foreign metal objects into the unit.

Do not submerge the device into water or other liquids.

Do not cover the device while it is use.

Please unplug the unit from the power source before commencing cleaning or maintenance.

Household use only.

The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Keep the appliance and its cord out of reach of children less than 8 years.

Children should be supervised to ensure that they do not play with the appliance.

CAUTION

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.