




**Domain Shelter**  
Model No. KC074-818

## PITCHING INSTRUCTIONS




### Your tent includes:

- 27 x pegs
- 4 x guy ropes
- 8 x webbing ropes

1. Select a dry, level site and clear the ground of any sharp objects. Remove the shelter from its carry bag, untie fabric ties and unroll the shelter.
2. Spread out the tent and peg out the four main corners ensuring the tent is pulled taut and square.
3. Unroll the webbing straps from the corners and connect them to the side release buckles on the corresponding corner. This stops the corners from 'splaying' out when the shelter is inflated.




4. Screw the valve into the air tube and then unscrew the valve cap that is on the top. Insert the pump hose into the valve and inflate. You may need to help the tube stand up so it inflates evenly. Inflate the middle tube first then move to the front and then the back. Make sure you only inflate to the recommended pressure (6-8psi) as over inflation can lead to tube damage. Only use the pump provided as it has a pressure gauge which shows the recommended pressure.



5. Step back and check the shelter is square. If so, peg out the remaining pegging points on the four corners first, followed by the curtains. It is important to rope out the guy ropes and webbing ropes on all sides to support the shelter in place.

6. The Domain air frame shelter is designed for short stays - overnight camps and day trips. Due to the air frame design it is not suited for long camping periods.

7. Fine tune the cover so it remains taut and positioned correctly over the frame.




### REVERSE THE PROCEDURE TO LOWER THE SHELTER

### PACKING INSTRUCTIONS

Pull out the pegs leaving the 4 corner pegs in.

Unscrew the valve caps letting out all the air - make sure all the air escapes and then lay the roof evenly on the floor as flat as you can as this will make the shelter easier to fold.



## SHELTER CARE INSTRUCTIONS

PLEASE READ ALL OF THE SHELTER CARE INFORMATION AND INSTRUCTIONS INCLUDED WITH THIS SHELTER BEFORE USING YOUR SHELTER FOR THE FIRST TIME.

1. Before you use your new shelter, fully unpack and pitch it at home. It is important to familiarise yourself with the set up procedure and the various features.
2. Select a site that is level, clear of any sharp objects, is dry, will drain well if it rains and is protected from wind and other elements.
3. Keep clear of overhead power lines and trees when setting up your shelter.
4. For best and easiest results, enlist the help of at least one other person to assist in pitching the shelter.
5. Keep all flame and heat sources away from this shelter fabric. Do not use open flame or gas appliances in or near your shelter.
6. Do not use aerosol sprays or any solvent based products in or around your shelter as these could damage the fabric or special coatings. These products include but are not limited to: repellent spray, hair sprays, alcohol, detergents, fly spray, petrol, kerosene etc.
7. Please note, the warranty on this shelter will be deemed void if the product is used for any purpose other than a temporary, recreational use shelter.
8. DO NOT leave shelter pitched for weeks at a time as extended exposure to the sun's ultraviolet rays can damage and/or cause it to discolour. Your shelter will not be covered under warranty if you leave it up for many weeks at a time. To avoid the risk of UV deterioration, site the shelter in a shaded area, where it will be protected from exposure to strong sunlight.
9. Especially in windy conditions, it is essential that you attach guy ropes and fasten them to the ground. We suggest you insert the pegs into the ground at a 45° angle towards the shelter, not straight down. Please note, your shelter will not be covered under warranty if wind damage occurs.
10. Hold the flaps up, when closing the doors, to take pressure off the zips. Ensure that the shelter fabric is never over stretched, especially as this may cause problems with the internal doors.

11. To clean your shelter, only ever use a soft sponge and warm water. DO NOT use excess force or other harsh cleaners to remove marks from shelter.
12. Ensure the shelter is completely dry and clean before storing away and ensure to store it in a dry environment.
13. Please note that the valves used on this product rely on a good air seal which can fail and become ineffective if left under compression whilst in storage. To reduce the chance of valve malfunction, the valves should be fully unscrewed when the product is in storage. Replacement valves are available from your stockist.
14. Please note, that the inflatable bladders are not repairable. Spare inflatable bladders, with full instructions, are available to purchase from your stockist.
15. Changing atmospheric conditions can make the air tubes appear to lose or in some cases gain pressure. Commonly caused by rising or lowering in ambient temperature. Should this occur, the tube will simply require either a topup or release of excess pressure. It should NOT be considered a sign of leakage or puncture. However, where leakage is suspected, you should firstly inspect the valve to ensure that no parts are cross-threaded and that the air seals are in good condition and tight. Removing a valve then re-fitting and re-inflating may help. If you discover that a valve has become faulty or a bladder has developed a leak, spares are available to purchase from your stockist.

### IMPORTANT:

1. Under certain conditions (cold weather, high humidity etc.) condensation may form on the inside of your shelter. Condensation can occur for many reasons including vapour from your breath, perspiration, cooking nearby or wet clothing inside your shelter. This does NOT mean your shelter is leaking through the fabric. You can minimise condensation by opening windows (if included) and airing out your shelter during the day and by removing any wet clothing/towels etc.
2. Try to avoid pitching your shelter under trees as tree limbs, falling leaves, sap, bird droppings or excess water dripping from the trees can cause damage to the shelter fabric and its special coatings resulting in leakage or discolouration.

3. Only remove the shelter pegs by pulling on the peg itself. NEVER pull on the shelter or the webbing loops to remove pegs as it could result in damage to the shelter or personal injury.
4. DO NOT leave shelter pitched for weeks at a time as extended exposure to the sun's ultraviolet rays can damage and/or cause it to discolour. Your shelter will not be covered under warranty if you leave it up for many weeks at a time.
5. STORAGE:  
NEVER store your shelter wet or dirty (even for short periods of time).  
NEVER store your pegs inside your shelter. Always use the separate bags they are supplied in.
6. You may want to insure your shelter against loss or damage.

## WARRANTY INFORMATION

The warranty period for this shelter is found on the packaging and full details are on the Kiwi Camping website - [www.kiwicamping.co.nz](http://www.kiwicamping.co.nz).

### Key points:

The original purchaser of this product is offered a warranty if during this time period the product fails due to a fault in either materials or workmanship. Service under this warranty is available by returning the product, with your proof of purchase, to where it was purchased. If after inspection it is determined that the product is defective, we will repair or replace it (at our discretion) free of charge. This warranty does not cover misuse, damage caused by accident, storm or wind damage, mildew, neglect, UV degradation and fair wear and tear. Please note, the warranty on this shelter will be deemed void if the product is used for any purpose other than a temporary shelter. If the claim is not deemed a warranty or is outside it's warranty period, we can repair the product at a nominal cost.



Distributed by: Aber, Hamilton, NZ  
[www.kiwicamping.co.nz](http://www.kiwicamping.co.nz)  
4825-09/17