



Easy-Fold Stretcher

Model No. KC024-108

WARNING:

- Adult assembly required.
- Keep screws and small parts out of the reach of children.
- Assemble on a flat level surface.
- To avoid injury to hands and fingers, use care when folding stretcher legs.

Step 1

Remove stretcher from carry bag and position standing upright, then unbuckle as shown.



Step 2

Spread out the stretcher by pulling apart at the ends to open the legs. This will leave the middle leg section vertical as shown.



Step 3

Open the stretcher by folding out each end leg section as shown. Spread out the stretcher by pulling apart at the ends to open the legs.



Step 4

Lock leg clamps into place, then pull legs out straight as shown.



Step 5

Carefully rotate the stretcher to the upright position. Ensure outside legs are fully expanded and extended before using the stretcher.



Distributed by: Aber, Hamilton, NZ
www.kiwicamping.co.nz

4703-07/17