



Easy-Fold Double Stretcher

Model No. KC024-134

WARNING:

- Adult assembly required.
- Keep screws and small parts out of the reach of children.
- Assemble on a flat level surface.
- To avoid injury to hands and fingers, use care when folding stretcher legs.

1. Remove stretcher from carry bag and position standing upright as shown.



2. Spread out the stretcher by pulling apart at the ends to open the legs. This will leave the middle leg section vertical as shown.



3. Open the stretcher by folding out each end leg section as shown. Spread out the stretcher by pulling apart at the ends to open the legs.



4. Carefully rotate the stretcher to the upright position. Ensure outside legs are fully expanded and extended before using the stretcher.



Distributed by: Aber, Hamilton, NZ
www.kiwicamping.co.nz

4744-07/17