

Wayfarer Queen Airbed


with built-in pump

Model No. KC026-127

Your bed includes:

- 1 x airbed with built-in pump
- 1 x carry bag
- 1 x repair kit

For better protection of this product, never unfold or inflate the airbed in temperatures below freezing, avoid extensive exposure to the sun and protect from contact with sharp objects and rough ground. Make sure to handle the pump with care. Avoid pounding and jumping to prevent damage to the airbed material.





INFLATION

Plug the power cable into a power point and turn on. Turn Comfort Adjust dial to desired firmness level. Turn Inflate/Deflate switch clockwise to "Inflate" position to turn on pump and inflate airbed.

Pump will automatically turn off upon reaching selected firmness level and Inflate/Deflate switch will automatically return to "Off" position. Airbed is ready for use.


You can change your comfort level by resetting the comfort dial. If you desire to change your comfort setting, turn Inflate/Deflate switch to deflate to release some air. Repeat the above steps. When complete unplug the power cable and put back into its storage compartment.





DEFLATION

Plug the power cable into a power point and turn on. For complete air removal, turn Inflate/Deflate switch counterclockwise to "Deflate" position.



Upon completion, pump will automatically turn off and Inflate/Deflate switch will automatically return to "Off" position. When complete unplug the power cable and put back into its storage compartment. Carefully fold to fit into carry bag.

IMPORTANT

- 1. Do not over inflate as this may cause damage to the bed and void warranty.
- 2. Do not leave your airbed in direct sunlight as this will weaken the fabric and cause the air pressure to increase.
- 3. Do not inflate airbed on rough ground, this may cause punctures.
- 4. Do not place excessive stress on the seams by jumping or bouncing.
- 5. This is not a floatation device.
- 6. Maximum weight capacity (evenly distributed): 230kg static weight.

TO REPAIR

- 1. Deflate the bed.
- 2. Clean and dry the damaged area to remove all traces of oil and grease.
- 3. Apply the glue, then patch immediately. Apply pressure for 2 minutes.
- 4. Apply glue to the edge of the patch for sealing purposes.
- 5. Allow 4 hours drying time before re-inflating the bed.